

# Turning the system on/off

**First step should always be to check to make sure you are on the correct Mode (Duplicate or Extend) using the Windows + P keys on the keyboard. Not doing this can result in losing the mouse pointer.**

## Turn on Room system:

1. Click anywhere on the touch panel on the instructor podium to begin.




2. Three preset settings will now be displayed on the screen (all three buttons turn the system on - read below for preset settings for quick scenarios)

***If you simply want to begin by using the computer and projection, select PC Main Overflow.***



- *Independent Mode* - this mode defaults to Solstice Main projecting to the front and Solstice Local on rear and side sources



- *Solstice Main Overflow* - this mode defaults to Solstice Main projecting to all three sources



- *PC Main Overflow* - this mode defaults to PC Main projecting to all three sources



### To Turn off Room system:

1. Click System Off
2. Click System Off button again to confirm. \*All three sources (both TVs and projector) will be off at this point.



Please Confirm System Off

